

ANVÄNDARGUIDE

Deltronic



**Batteridrivnen Optiskt Brandvarnare
Modell X10, Art nr. 10346**

Test av Brandvarnare

Varning använd hörselskydd!!!! (85dB vid 3m)

Tryck och släpp testknappen för att prova funktion. Brandvarnaren ska ljuda tre gånger med ett blinkande rött ljus och sedan stoppa. Efter testet kontrollerar du att den röda lampan blinkar ungefär varje minut. Testa larmet en gång i veckan för att säkerställa korrekt funktion.

Notera! Testknappen ger ett fullständigt test av brandvarnaren. Försök inte att testa larmet med hjälp av antingen värme, rök eller öppen flamma, detta kan skada enheten.

Skötselansvisning

Ett regelbundet program för underhåll av brandvarnare hjälper till att hålla ditt skydd i gott skick.

- Kontrollera varnare varje vecka och se till att alla eventuellt sammankopplade varnare i systemet ljuder inom 10-20 sekunder.
- Dammsug larmet var sjätte månad och torka det med en lätt fuktad trasa för att avlägsna eventuell smuts.
- Täck inte över varnaren.
- Täck över brandvarnaren när det utförs dammrika arbeten såsom slipning av golv eller väggspackel. En brandvarnare är en känslig livförsäkring, livslängden för denna varnare kan minskas avsevärt på grund av

bristande regelbundet underhåll och i vissa fall komma att häva er rätt till att åberopa garanti.

Användarinformation

Skydda ditt hem mot brand:

Besök räddningstjänstens hemsida för att hitta hjälp för att utforma ditt brandskydd, denna information är fri och identifierar potentiella brandfaror i och runt ditt hem. Se även till att alla boende i fastigheten vet hur ett brandlarm låter:

Normalt bevakning läge	Röd LED blinkar varje minut	Inget ljud
Fullt alarm rök detekterad	Repeterande serie av 3 pip var fjärde sekund med blinkande ljus	••• ••• ••• •••
Låg batteri nivå	Ett pip varje minut	• • • •
Testknappen har fastnat	Ett pip med 11 sekunders intervall	• • • •
Fel	Dubbelt pip varje minut	•• •• •• ••

Förebyggande åtgärder:

- Skapa en utrymningsplan med en uppsamlingsplats en bit bort från byggnaden/fastigheten.
- Öva hur man agerar under ett skarpt läge.
- Finns det någon brandbekämpningsutrustning, om ja, var finns den och vem kan använda den?
- Vem gör vad? Är det möjligt att fördela upp olika ansvarsområden?
- Lämnar inte stearinljus utan övervakning, hantera nyligen utbränd aska med stor försiktighet.
- Gör regelbundet en hälsokontroll av elektriska apparater och installationer.
- Förvara tändstickor/tändare oätkomligt för barn.
- Förvara inte brandfarliga eller explosionsfarliga vätskor i närheten av värmekällor.
- Var försiktig med brandfarliga textilier/gardiner i närheten av fönster eller bord med levande ljus.
- Komplettera gärna ditt brandskydd med brand

filt eller släckare.

Vad ska man göra om larmet låter?


- Se till att alla lämnar byggnaden så snart som möjligt. Kontrollera så att ingen lämnas kvar!
- Spring inte, lämna kvar personliga tillhörigheter.
- Om det är säkert att göra det, stäng alla fönster och dörrar när du utrymmer lokalen/området, detta för att förhindra brandspridning.
- Ring brandkåren på **SOS 112**
- Rök är den främsta orsaken till dödsfall från eld, om du är fångad inuti en byggnad, täck din mun, spara på andetag och kryp nära golvet fram till säkerhet. Stå inte upp mer än nödvändigt!
- Om möjligt, försök att begränsa/släcka elden.

• Återställ inte ett brandlarm tills du vet orsaken till larmet och när alla personer är i säkerhet!

Demontering / Montering

• Demontering


Tryck in låskilen som sitter i sidoväggen enligt bild och vrid samtidigt Brandvarnaren motsols. Tag sedan loss Brandvarnaren.



• Montering

Rikta in pilen på brandvarnarens baksida mot pilen inuti monteringsplattan, när brandvarnaren är inriktad rätt och plant mot monteringsplattan vrid medsols tills låskilen klickar på plats.

Brandvarnaren aktiveras nu automatiskt.



Enheten har inbyggt batteri!

Fördjupad information hittar du på vår hemsida under respektive produkt.
www.deltronic.se

Deltronic Security AB
E A Rosengrens gata 4
SE-421 31 Västra Frölunda
info@deltronic.se
Tel: +46 (0)31-14 08 00

USER GUIDE

Deltronic



**Battery operated Smoke alarm
Model X10, Art no. 10346**

Test of Smoke Alarm

Warning use hearing protection !!! (85dB at 3m)

Press and release the test button. The smoke alarm should sound three times with a flashing red light and then stop. After the test, make sure that the red LED light flashes approximately every minute. Test the alarm once a week to ensure proper operation.

Note! The test button provides a full test of the alarms functionality. Do not try to test the alarm using either heat, smoke or naked flame as damage will occur to the unit.

Alarm Maintenance

A regular program of fire alarm maintenance will help to keep your alarm in good working order.

- Test the alarm monthly making sure that all interconnected alarms in the system sound within 10-20 seconds.
- Vacuum the alarms every six months and wipe them with a damp cloth.
- Do not paint the alarm.
- Cover the fire detector when performing dust rich work, such as grinding of floor or wall rack. A smoke alarm is a sensitive life-saving device. The life of this alarm can be significantly reduced by failure to regularly clean and maintain it according to the instructions.

Lack of reasonable care may also cause it to malfunction and will invalidate the warranty.

User Information

Protect your Home Against Fire

Check out your local Fire Brigades home page for a home safety check, this information is free and will identify potential fire hazards in and around your home. It's a good guide to help your selves. Make sure all occupants of the home know what a fire alarm sounds like and what to do when:

Normal mode	Red Flashes every minute no sound	
Full alarm indicating smoke and fire	Repeating series of 3 beeps every 4 seconds with flashing light	••• ••• ••• •••
Low battery Level	Single beep every minute	• • • •
Test button jammed	One beep every 11 seconds	• • • •
Fault	Double beep every minute	•• •• •• ••

Preventive actions:

- Set up an escape plan and decide an assembly point in a safe area away from the building.
- Practice how to act during a real fire.
- Is there any fire fighting equipment, where and who can use it properly?
- Who is doing what? Is it possible to address different areas of responsibility? Upper, Lower...
- Don't leave candles unattended, don't handle recently put out ashes recklessly!
- Do a health check on electrical devices/cables.
- Keep matches / lighters out of reach of children.
- Do not store flammable or explosive liquids near heat sources.
- Be careful of flammable textiles/curtains near windowsills or candlelit tables.
- Please complete your fire protection with fire blanket

or extinguisher.

What to Do if the Alarms Sound?


- Ensure everyone leaves the building as soon as possible. Check all areas so no one is left behind!
- Do not run nor stop to collect belongings.
- If it is safe to do so, close all windows and doors as you escape to prevent the spread of fire.
- Call the fire brigade at **SOS 112**
- Smoke is the main cause of death from fire. If trapped inside the building, cover your mouth, conserve breath and crawl near the floor to safety.
- If possible try to limit/put out the fire, but do not risk your selves or others life doing so.

Do not silence a fire alarm until you know the cause of the alarm and when all occupants are safely outside the building!

Disassembly / Assembly


• Disassembly

Push in the locking key located in the side wall as shown and at the same time turn the smoke alarm counter clockwise. Then remove the smoke detector.



• Mounting

Align the arrow on the rear of the smoke detector with the arrow inside the mounting plate, when the smoke detector is aligned on the mounting plate turn clockwise until the locking key clicks into place. **The smoke alarm is now activated automatically.**



The unit has a built in battery!

More detailed information can be found on our website under each product, welcome.
www.deltronic.se

Deltronic Security AB
E A Rosengrens gata 4
SE-421 31 Västra Frölunda
info@deltronic.se
Tel: +46 (0)31-14 08 00